



COLOR-PAVE LTD

MANUFACTURERS OF POWDERS, RELEASES, SEALERS AND CLEANERS

THE APPLICATION OF ART-REND PRINTED WALL SURFACE

TECHNICAL SUPPORT

Unit 4, Leachfield
Industrial Estate, Green
Lane West
Garstang, Preston
Lancashire
PR3 1PR

sales@color-pave.co.uk

THE PROCESS OF APPLYING ART-REND TEXTURE WALL COATING AND DESIGN

- 1. APPLICATION: ART-REND IS APPLIED IN A TWO STEP PROCESS.**
- 2. THE BACKGROUND IS FIRST PRIMED WITH ART-REND PRIMER.**
- 3. THE FIRST COAT OF APPROXIMATELY 12MM IS APPLIED AS A SCRATCH COAT. IF THE FINAL FINISH IS TO BE BRICK OR WOOD, THIS FIRST COAT CAN BE SMOOTHED READY FOR TINTING.**
- 4. IF A DEEP TEXTURE STONE FINISH IS DESIRED A SECOND APPLICATION OF RENDER CAN BE APPLIED. THIS CAN BE APPLIED VERY UNEVENLY, ALMOST LIKE A "DOT & DAB" TECHNIQUE. THIS SECOND COAT CAN THEN BE SMOOTHED READY TO TINT.**
- 5. TINTERS ARE APPLIED FROM OUR "TRIGGER SPRAY APPLICATORS OR LOW PRESSURE SPRAY POTS. ONCE THE DESIRED COMBINATION OF TINTERS HAS BEEN APPLIED, THE SURFACE IS THEN TROWELLED TO BLEND IN THE COLOURS INTO THE BACKGROUND RENDER.**
- 6. TEXTURING OR IMPRINTING CAN NOW TAKE PLACE. AFTER A SET PERIOD (NORMALLY NEXT DAY). YOU CAN CARVE THE OROUT LINES AND A00LV OTHER AOEINO CHEMICALS**